





## SUZUKI GSF 600/1200 Bandit

Schutzbügel  
Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

|     |        |
|-----|--------|
| M6  | 9,6 Nm |
| M8  | 23 Nm  |
| M10 | 46 Nm  |

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

Maximale Zuladung der Koffer :  
Gemäß Herstellerangaben

SW-MOTECH GmbH & Co. KG  
Bahnhofstrasse 44d  
35282 Rauschenberg  
-Germany-

Tel.: ++ 49 (0) 6425 816 800  
Fax: ++ 49 (0) 6425 816 810

www.sw-motech.com

Crash Bar  
Mounting Instructions

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW-MOTECH takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

|     |        |
|-----|--------|
| M6  | 9,6 Nm |
| M8  | 23 Nm  |
| M10 | 46 Nm  |


All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.

1 Schutzbügel lks./rts.  
Crash Bar


SBL.05.341.901/902

Anzahl/ Pcs. 2 (L/R)

5 Zylinderschraube  
mit Innensechskant  
Hexagon Socket  
Screw


M8 x 70 DIN 912

Anzahl/ Pcs. 4

9 Distanzbuchse  
Spacer  
!GSF 600 Bandit!

Da:20 Di:10,5 h:24

Anzahl/ Pcs. 2

2 Zylinderschraube  
mit Innensechskant  
Hexagon Socket  
Screw

M10 x 85 DIN 912

Anzahl/ Pcs. 2

6 Unterlegscheibe  
Washer

A 8,4 DIN 125

Anzahl/ Pcs. 4

3 Federring  
Retaining Ring

M10 DIN 127

Anzahl/ Pcs. 2

7 Distanzbuchse  
Spacer

Da:14 Di:8.4 h:15

Anzahl/ Pcs. 2

10 Mutter mit Bund  
Lock Nut

M 10 DIN 6927

Anzahl/ Pcs. 2

4 Distanzbuchse  
Spacer  
!GSF 1200 Bandit!

Da:20 Di:10,5 h:3

Anzahl/ Pcs. 2

8 Distanzbuchse  
Spacer

Da:14 Di:8.4 h:10

Anzahl/ Pcs. 2

# GSF 600/1200 Bandit

