



HPS.07.628.100
Revision: 00

Hauptständer BMW G 650 X-Challenge & X-Moto & X-Country Centre Stand BMW G 650 X-Challenge & X-Moto & X-Country

Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

M10 46 Nm

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

Die Kurvenfreiheit kann durch einen Hauptständer eingeschränkt werden.

SW-MOTECH GmbH & Co. KG
Bahnhofstrasse 44d
35282 Rauschenberg
-Germany-

Tel.: ++ 49 (0) 6425 816 800
Fax: ++ 49 (0) 6425 816 810

www.sw-motech.com

Mounting Instruction

Centerstand cornering clearance: SW-MOTECH centerstands are carefully designed and tested to eliminate reductions in cornering clearance and ground clearance under most driving conditions on an unmodified stock motorcycle, and are certified to be compliant with European ABE safety standards. Use of any centerstand may reduce corning clearance or ground clearance under extreme driving situations.

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW-MOTECH takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M10 46 Nm

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts and nuts.

! Achtung: Die Kurven- und Bodenfreiheit kann durch einen Hauptständer eingeschränkt werden.

Attention: Cornering and ground clearance can be reduce by using a centre stand.

1 Hauptständer
Centre Stand



HPS.07.628.900 00
Anzahl/ Pcs. 1

2 Befestigungsblech,
links
Fixing Bracket
left side



HPS.07.628.901 00
Anzahl/ Pcs. 1

5 Befestigungsblech mit
Federanlenkung, rechts
Spring Bracket
right side



HPS.07.628.902 00
Anzahl/ Pcs. 1

3 Senkkopfschraube
Counter Sunk Screw



M10 x 45 DIN 7991
Anzahl/ Pcs. 1

6 Senkkopfschraube
Counter Sunk Screw



M10 x 40 DIN 7991
Anzahl/ Pcs. 2

4 Senkkopfschraube
Counter Sunk Screw



M10 x 35 DIN 7991
Anzahl/ Pcs. 1

7 Distanzbuchse
Spacer




Da:20 Di:10,5 h:3
Anzahl/ Pcs. 2

8 Zugfedersatz
Spring Set




ZFD.00.150.008/ST
Anzahl/ Pcs. 1



Rechte Seite / right side

Fahrtrichtung
Driving direction



! Achtung: mit Schmierfett einsetzen!
• Attention: insert with grease!



Linke Seite / left side

Fahrtrichtung
Driving direction

! Achtung: mit Schmierfett einsetzen!
• Attention: insert with grease!



Montage der
Zugfeder (8).

Mounting of the
spring set (8).

INFORMATION

Zugfeder-Montagewerkzeug
(WFF.00.138.100) separat erhältlich.

Spring mounting tool (WFF.00.138.100)
sold separately.